

Nylon Clip Installation Instructions

- 1 Set joist centres for the deck sub frame at 350mm.
- 2 Drill a 2mm pilot hole and fix the clip into the groove on the side of the deckboard.
- 3 Fix the clip with 1 x 50mm screw through the central hole.
- 4 At butt joints where 2 boards join, make sure you leave a 5mm gap for expansion. Every butt joint should be secured with 2 clips. Offer up the clips into the groove on the side of the deckboards. Fix the clips with 1 x 50mm screw, each through the one central hole.
- 5 At the edge of the deck locate the end of the clip base flush with the end of the deckboard so the screw is no more than 22mm from the end of the deckboard.
- 6 Once you have a complete row of decking installed, offer up the next row of decking inserting the edge of the clips into the groove on the side of the deckboard. Gently tap into place with a rubber mallet if necessary.

